


RUB 642



ADPT 109R

Design  
Cap



# ADPT 109RA

## SPOUT EXTENDER ASSEMBLY

Install the RUB 642 o-ring inside the upper rim of the ADPT 109R and snap the design cap onto the bottom of the ADPT 109R spout extender.